Lecture 1: Overview of Optical Communications Links and Intro to Photodetection


Overview of Optical Communications Links

Fiber-Optic Network Applications


- ⇒ Main application: digital transmission
 - ⇒ Voice, telephone
 - ⇒ Data
 - ⇒ IP Networks
 - ⇒ ATM, Gigabit Ethernet, FDDI, etc.
 - ⇒ Distributed Computing and Databases
 - ⇒ Video, Multimedia
- ➡ Microwave Photonics
 - ⇒ Fiber/Wireless
 - ⇒ Hybrid Fiber/Coax
- ⇒ Other applications
 - ⇒ Fiber/Wireless
 - ⇒ Hybrid Fiber/Coax

Note:

Traffic generated by datacentric application (mainly IP) is rapidly surpassing the voicecentric traffic





Technology Push and Integration Trends



Power and Size: The Next Frontier

- Decreased transistor size, 2x transistors on chip every 18 months, increased frequency
- Leakage current is huge problem, chips (hence systems) become power constrained
- New transistor technologies aim to decrease leakage current but requires new processing infrastructure.
 Costly to roll over to new foundries from current.
- Moving to multi-processor cores to keep up performance without increasing speed








The Power Bottleneck

Maximum configuration: 92Tbps

→ 72 x LC chassis + 8 x Fabric chassis


- ⇒ Transistors power dissipated on every bit
 - ⇒ Faster frequency more power dissipated
 - Power scales linearly with message length
 - ⇒ Regenerative technology
- ⇒ Optics
 - ⇒ Pay initial bias power price
 - ⇒ Faster data frequency does not add power (due to data relative to carrier frequency)
 - ⇒ Switching on boundaries only
 - ⇒ Loss and SNR is key issue
 - ⇒ Regeneration

From Garry Epps, Cisco Systems



Shortfall is overcome by architectural innovation and trading off:
Performance, functionality, programmability, physical size/density → Very hard to sustain long-term


Transmission Bandwidth Evolution




Evolution of Fiber-Optic Point-to-Point Transmission

Multimode fiber-optic waveguides >5dB/km attenuation	Low loss Single mode optical fibers 1 dB/km @ 1310 nm	Operation in the low loss window of 0.2 dB/km @ 1550 nm but high dispersion @ 1550 nm Mid to L	ate 80s	Multichannel erbium doped fiber amplifiers (EDFAs) @ 1550 nm deployed.	90s	AT&T True Wave Fiber and Corning Large Optical Core Fiber reduce fiber FWM	
Early 70s Room temperature GaAs LEDs and multimode FP Lasers @ 830 nm	Multimode Fabry-Perot 1310 nm lasers	Development of single frequency DFB 1310 nm and 1550 nm lasers	New disp shifted fill yields Ze dispersion 1550 nm dB/km lo 1310 nm	per ro n @ and 0.5	Mu WE Nun cha cha limi	d 90s Itichannel OM @1550 nm. Inber of Innels and Innel spacing Ited by fiber Ited by fiber Ited wave mixing Ited WM)	Mid 90s Optical Solitons, dispersion compensation
← 1st Generation	2nd Generation	• ∢ 3rd Generati	→ on	4th Ger	erat	ion	◆ 5th Generation

DWDM Link Evolution



Basic Fiber Optic Point-to-Point Link



Basic Communication System



Block Coding

- •Error Correction
- •Redundancy
- •Overcome noise and transmission impairments
- •E.g. FEC, Turbo-Codes

Line Coding


- •DC balance
- •Redundancy
- •E.g Manchester Codes

Link Capacity and Spectral Efficiency

- ⇒ Capacity of an optical communications channel is the maximum bit rate that can be transmitted without error for a given noise, bandwidth and power.
- Capacity can be calculated independent of modulation, coding or decoding technique
- ⇒ For a WDM (Wavelength Division Multiplexed) optical communications system

S = Spectral Efficiency =
$$\frac{\text{Capacity per Channel}}{\text{Channel Spacing}} = \frac{C}{\Delta f} = \frac{\text{Bits/Second}}{\text{Hz}}$$

Signal to Noise Ratio (SNR)




Multiplexing Techniques


Multiplexing Techniques

- ⇒ Multiplexing is the technique used to carry several different information channels on a common physical medium. The standard techniques are:
 - ⇒ Time Division Multiplexing (TDM)
 - ⇒ Frequency Division Multiplexing, indicated as "Wavelength Division Multiplexing" (WDM) in optics
 - ⇒ Space Division Multiplexing (SDM)
 - ⇒ Code Division Multiplexing (CDMA)
 - ⇒ Multilevel coding

Time Division Multiplexing (TDM)




Wavelength Division Multiplexing (WDM)



ECE228B, Prof. D. J. Blumenthal

Lecture 1, Slide 17

Wavelength/Subcarrier Multiplexing



Optical Modulation

Modulation Basics (I)

⇒ Define

- \Rightarrow R_b = bit rate = bits/second
- ⇒ R_c = added redundancy per bit to improve SNR = baud = symbols/second
- \Rightarrow B = occupied bandwidth per channel
- \Rightarrow M = number of points in signal constellation
- ⇒ Binary Modulation
 - ⇒ One bit per symbol
- ⇒ Non-Binary Modulation
 - ⇒ More than one bit per symbol
- ⇒ No inter-symbol interference (ISI)
 - $\Rightarrow R_{s} \leq B$
- ⇒ Error correction
 - $\Rightarrow R_c \leq 1$
- ⇒ No error correction


$$\Rightarrow R_c = 1$$

Information bit rate per channel in one polarization state

$$R_b = R_s R_c \log_2 M$$


Binary Intensity Modulation

⇒ The primary modulation format used for commercially deployed optical systems are intensity modulation (optical power modulation)




Optical spectrum for intensity modulation

- ⇒ If the intensity modulation is imposed to the optical signal together with unwanted phase or frequency modulation (e.g chirp under direct laser modulation, excess laser phase noise)
 - ⇒ The resulting optical spectrum is larger than the bit rate
- ⇒ If the modulation is a (nearly) pure intensity modulation, without any accompanying phase/frequency shift (e.g. external modulation)
 - ⇒ The resulting spectrum has a primary lobe that occupies the order of the bit rate




Coherent Binary Modulation




Binary Signal Constellations

Binary Intensity Modulation/Direct Detect (IM/DD)



Two-Level PSK



M = average power in 1 bit

 σ_0 = variance of signal independent noise


 P_s = average signal power

 P_{LO} = average local oscillator power

T = bit period

Quadrature Multi-Level Modulation

- ⇒ Both optical phase and amplitude can be used to code symbols per bit
- N-ASK is N-level amplitude shift keying (generalization of ASK): along amplitude axis
- N-PSK is N-level phase shift keying (PSK): along phase axis
- N-QAM is quadrature amplitude modulation: 2D in amplitude and phase
- Receiver must isolate one point in constellation per bit
- Noise makes more difficult to isolate symbol (SNR)
- ⇒ 2-D space can be increased to 3 and 4-D by allowing temporal modulation of phase and amplitude




Photodetection

Detection of Optical Signals

- ⇒ Thermal: Temperature change with photon absorption
 - ⇒ Thermoelectric
 - ⇒ Pyromagnetic
 - ⇒ Pyroelectric
 - ⇒ Liquid crystals
 - ⇒ Bolometers
- ⇒ Wave Interaction: Exchange energy between waves at different frequencies
 - ⇒ Parametric down-conversion
 - ⇒ Parametric up-conversion
 - ⇒ Parametric amplification
- ⇒ Photon Effects: Generation of photocarriers from photon absorption
 - Photoconductors
 - ⇒ Photoemissive
 - ⇒ Photovoltaics

Photon Statistics

- ⇒ Photon sources can in general be characterized as coherent or incoherent[†]
 - \Rightarrow Coherent: Probability that a photon is generated at time t_0 is mutually independent of probability of photons generated at other times (Markov Process)
 - \Rightarrow Poisson Process: Probability of finding *n* photons in time interval *T*
 - ⇒ Bunching is a trait of the Poisson process
 - ⇒ Interarrival time is decaying exponentially distributed



$$P(n \mid T) = \frac{(rT)^n e^{-rT}}{n!}$$

† Can also be a combination of these two types -> partially coherent


Where:

P(n|T) is probability of finding n photons in time interval T

R is mean photon arrival rate (photons/second)

Photon Statistics (II)

- ⇒ Narrowband Thermal (Gaussian):
 - \Rightarrow Bose-Einstein Process: Probability of finding *n* photons in time interval *T*



$$P(n) = \left(\frac{1}{1+n_b}\right) \left(\frac{n_b}{1+n_b}\right)^n$$

Where:

P(n) = probability of finding n photons given

 n_b = mean number photons from incoherent source = N_0/hv_0

 N_0 = spectral density of source = P_{opt}/B_0


 P_{opt} = total optical power from source

 B_0 = source optical bandwidth

 $T = observation time \le 1/B_0$

Detecting Photons (1)


- Any material that can respond to single photons can be used to count photons
- ⇒ Ideal Detector
 - Generation of a electron-hole pair per absorbed photon results in an instantaneous current pulse



Detecting Photons (2)

⇒ Real Detector

- \Rightarrow Has an inherent "impulse response," $h_d(t)$, due to built in resistance and/or capacitance.
- ⇒ Can be modeled as an RC filter with low pass response



Detecting Photons (3)

- As the average photon rate increases, the observed photo-current starts smoothing out, with a variance around the mean (average) count that is based on the statistics (which tends to Gaussian for large photon arrival rate)
- \Rightarrow P(i) is the probability function of measuring the current at a certain value at time t.

